

Backup "SET" and "USER PROGRAM" memory on Roland FR-4x

Test a USB memory stick by trying the RECORD function to be certain the 4x can read the memory stick. Use a new stick – or – an old one that has been completely deleted. The 4x prefers small memory sticks; a 2GB stick is fine for this project.

1 Place accordion on table. Insert memory stick with accordion turned OFF, then power ON

2 Menu/Write

3 > button (right button) 12 times to read UTILITY

4 Enter/Yes

5 > button 7 times to read EXPORT

6 Enter/Yes (screen reads: Type: SET)

7 > button 18 times (screen reads: WRITE? N Y

8 Enter/Yes (screen reads: EXPORTING for a few seconds, then reads: Type: SET)

At this point the SET memories have been backed up. Now, continue on to back up the USER PROGRAMS

9 + button 1 time (screen reads: Type: UPG)

10 > button 1 time (screen reads: UPG File ALL)

11 > button 18 times (screen reads: Write? N Y)

12 Enter/Yes (screen reads: Exporting, you will see the percentages flash through)

13 Screen reads: Type UPG

At this point both the SET Memories and the USER PROGRAM Memories have been backed up

DO NOT record more information on the USB stick. Turn OFF the accordion, then remove stick.

To verify your backup, place USB stick in computer. You will see two folders: MySET and MyUPG

Be certain to use computer function: Safely Remove Hardware and Eject Media, before removing USB stick from computer USB port. Label the stick and store where you will remember what information it contains.

Dale Mathis Sound Set Programming exclusively for Crown Music, Sun City, Arizona 623-374-6423