

FR-4x

Tone & Drum Kit List

V-Accordion

Contents

Set List.....	2
Orchestra Tone List.....	3
Controlling the Dynamics of the Orchestra Sound	4
Organ Tone List.....	6
Drum Tone List.....	7
User Program List.....	10

Set List

This is the set list when the instrument is shipped from the factory (following factory reset). It can be rewritten.

No.	Set name
1	Hello 4X
2	NewCLASC
3	NewMUSSET
4	NewTANGO
5	NewDANCE
6	NOR CASS
7	NOR WAY
8	FIN TRAD
9	FIN 2000
10	A Favor
11	A Jazz
12	A Paris
13	A Techno
14	A Polka
15	Brazil 1
16	Brazil 2
17	Brazil 3
18	Brazil 4
19	Brazil 5
20	CONCERTO
21	CLASSIC
22	JAZZ
23	FJAZZ
24	'I' SCALA
25	BAJAN
26	'I' FOLK
27	'D' FOLK
28	'F' FOLK
29	'SP' FOLK
30	BallROOM
31	BANDNEON
32	ALPINE
33	CAJUN
34	TEX MEX
35	OldPARIS
36	CiaoROME
37	DiatFOLK
38	STUDIO
39	TRDITION
40	BAROQUE
41	ROMANTIC
42	CONCERTN
43	SCOTTISH
44	IRISH
45	CELTIC
46	XLowReed
47	HalfVALV
48	FUTURE
49	MUSETTE
50	BASSOON
51	MASTER
52	V-Set
53	FIN CASS
54	Kravatti

No.	Set name
55	Balkan
56	WOA1-Ac
57 (*1)	Balkan 1
58 (*1)	Balkan 2
59 (*1)	Balkan 3
60 (*1)	Balkan 4
61 (*2)	1871
62 (*2)	LITURGI1
63 (*2)	LITURGI2
64 (*2)	ORGANTON
65 (*2)	CENTENAR
66 (*2)	SM_1965
67 (*2)	SM_2010
68	EMPTY
69	EMPTY
70	EMPTY
71	EMPTY
72	EMPTY
73	EMPTY
74	EMPTY
75	EMPTY
76	EMPTY
77	EMPTY
78	EMPTY
79	EMPTY
80	EMPTY
81	EMPTY
82	EMPTY
83	EMPTY
84	EMPTY
85	EMPTY
86	EMPTY
87	EMPTY
88	EMPTY
89	EMPTY
90	EMPTY
91	EMPTY
92	EMPTY
93	EMPTY
94	EMPTY
95	EMPTY
96	EMPTY
97	EMPTY
98	EMPTY
99	EMPTY
100	EMPTY

*1 The “Balkan” expansion sound data must be loaded as described in “Loading Expansion Sounds” of the reference manual.

NOTE

- The “Balkan” expansion sound data is already preloaded when the instrument is shipped from the factory.
- If this data is not loaded, there will be no sound.

*2 The “Dallapé” expansion sound data must be loaded as described in “Loading Expansion Sounds” of the reference manual.

NOTE

- The “Dallapé” expansion sound data is already preloaded when the instrument is shipped from the factory.
- If this data is not loaded, there will be no sound.

Orchestra Tone List

No.	Full Name	FR-4x Name	What can be controlled
1	NaturalPiano	NatrIPno	Keyboard
2	SuperiorPiano	SuperPno	Keyboard
3	European Pf	EuropePf	Keyboard
4	Rock Piano	Rock Pno	Keyboard
5	Honky Tonk	HonkyTnk	Keyboard
6	RD Piano	RD Piano	Keyboard
7	Piano+String	Pno+Str	Bellows + Keyboard
8	Piano+Choir	Pno+Cho	Bellows + Keyboard
9	Ac Piano	Ac Piano	Keyboard
10	Oct. Piano	OctPiano	Keyboard
11	Pure EP	Pure EP	Keyboard
12	El. Piano	El. Piano	Keyboard
13	Wurly	Wurly	Keyboard
14	EP Heaven	EPHeaven	Bellows + Keyboard
15	Clavi	Clavi	Keyboard
16	Phase Clav	Phs Clav	Keyboard
17	Harpsi w	Harpsi w	Keyboard
18	HarpsiStr	HpsiStr	Bellows + Keyboard
19	Vibe	Vibe	Keyboard
20	Marimba w	Marmba w	Keyboard
21	Xylophone w	Xylphn w	Keyboard
22	Celesta	Celesta	Keyboard
23	Music Box	MusicBox	Keyboard
24	Rotary B3	Rotary B	Bellows
25	Organ Flute	OrganFlt	Bellows
26	Chapel Organ	ChaplOrg	Bellows
27	Mid Pipe	Mid Pipe	Bellows
28	Church Organ	ChrchrOrg	Bellows
29	G-Accord 1	GAccord1	Bellows
30	G-Accord 2	GAccord2	Bellows
31	G-Accord 3	GAccord3	Bellows
32	C-Accord A1	CACcord1	Bellows
33	C-Accord A2	CACcord2	Bellows
34	C-Accord A3	CACcord3	Bellows
35	C-Accord N1	CACcord4	Bellows
36	C-Accord N2	CACcord5	Bellows
37	E-Accord 1	EACcord1	Bellows
38	E-Accord 2	EACcord2	Bellows
39	Harmonica	Harmonca	Bellows
40	Mute Harm	MuteHarm	Bellows
41	Nylon Guitar	Nylon Gt	Keyboard
42	Flamenco Guitar	Fmnc Gt	Keyboard
43	Ac. Guitar	AcGuitar	Keyboard
44	Steel Guitar1	SteelGt1	Keyboard
45	Steel Guitar2	SteelGt2	Keyboard
46	Nylon&Steel	NylIn&Stl	Keyboard
47	Cimbalon	Cimbalon	Keyboard
48	TamBPtrl	TamBPTrl	Keyboard
49	Banjo	Banjo	Keyboard
50	Mandolin	Mandolin	Keyboard
51	Clean Solid	CInSolid	Keyboard
52	JC Chrus Gt	JCChrsGt	Keyboard
53	Jazz Guitar	Jazz Gt	Keyboard
54	PedalSteel	PedalStl	Bellows + Keyboard
55	Warm Drive	WrmDrive	Keyboard

No.	Full Name	FR-4x Name	What can be controlled
56	Distort Gt.	DistortGt	Bellows + Keyboard
57	XV Ac. Bass	XVAcBass	Keyboard
58	Acoustic Bs1	Ac. Bass1	Keyboard
59	Acoustic Bs2	Ac. Bass2	Keyboard
60	Cb Sect	Cb Sect	Bellows
61	Bowed	Bowed	Bellows
62	Tuba	Tuba	Bellows
63	Tuba Mix	Tuba Mix	Keyboard
64	Fingered Bs1	FingrBs1	Keyboard
65	Fingered Bs2	FingrBs2	Keyboard
66	Fretless Bs1	FrtlsBs1	Keyboard
67	Fretless Bs2	FrtlsBs2	Keyboard
68	Picked Bs1	PickdBs1	Keyboard
69	Picked Bs2	PickdBs2	Keyboard
70	Nu Slap Bs	NuSlapBs	Keyboard
71	Bassic Needs	BscNeeds	Bellows + Keyboard
72	MG Bass	MG Bass	Bellows + Keyboard
73	SynthBass201	SynBs201	Bellows + Keyboard
74	SH101 Bass	SH101 Bs	Bellows + Keyboard
75	Rubber Bass	Rbr Bass	Keyboard
76	SymphStrings	SymphStr	Bellows
77	Sl. Strings	Slow Str	Bellows
78	Group Vls	GroupVls	Bellows
79	St. Slow Str	StSlwStr	Bellows
80	Velo Strings	Velo Str	Bellows
81	Strings	Strings	Bellows
82	Str.+Flute	Str+Flt	Bellows
83	Horn&Orc	Horn&Orc	Bellows
84	Str&Choir	Str&Cho	Bellows
85	Syn. Strings	Syn Str	Bellows
86	SC Violin	SCViolin	Bellows
87	Violin	Violin	Bellows
88	Cello	Cello	Bellows
89	Pizzicato	Pizz	Keyboard
90	Harp St.	Harp St.	Keyboard
91	Warm Voices	Warm Vox	Bellows
92	Fem Mm Srt	FemVoice	Bellows
93	Tears Voices	TearsVox	Bellows
94	ChorusLuh	Chrs Luh	Bellows + Keyboard
95	ChorusWoh	Chrs Who	Bellows + Keyboard
96	Pad Voices	PadVoice	Bellows + Keyboard
97	ChoirAahs	ChrsAahs	Bellows + Keyboard
98	JazzScat1	Jz Scat1	Bellows + Keyboard
99	JazzScat2	Jz Scat2	Bellows + Keyboard
100	JazzScat3	Jz Scat3	Bellows + Keyboard
101	JazzDoos	Jz Doos	Bellows + Keyboard
102	Oct Brass	OctBrass	Bellows
103	SC Brt Brass	SCBrtBrs	Bellows
104	Tp+Tb Sect	TpTbSect	Bellows
105	Brass Sforz	BrsSforz	Bellows
106	Brass	Brass	Bellows
107	Jump Brass	Jump Brs	Bellows
108	JUNO Brass	JUNO Brs	Bellows
109	Twin Trumpet	Twin Tp	Bellows
110	Trumpet	Trumpet	Bellows

Orchestra Tone List

No.	Full Name	FR-4x Name	What can be controlled
111	Soft Muted Trump	SoftMtTp	Bellows
112	Muted Trum	Mute Tp	Bellows
113	Trumpets & Fall	Tps&Fall	Bellows
114	V Twin bones	TwinBone	Bellows
115	Trombone	Trombone	Bellows
116	Alto Sax	Alto Sax	Bellows
117	Tenor Sax1	Tnr Sax1	Bellows
118	Tenor Sax2	Tnr Sax2	Bellows
119	Soprano Exp.	Sop Sax	Bellows
120	Sax Section1	Sax Sect	Bellows
121	FrenchHorn	Fr Horn	Bellows
122	Clarinet	Clarinet	Bellows
123	Flute1	Flute1	Bellows
124	Flute2	Flute2	Bellows
125	PanFlute	PanFlute	Bellows
126	Oboe	Oboe	Bellows
127	Bassoon	Bassoon	Bellows
128	Piccolo	Piccolo	Bellows
129	Whistle	Whistle	Bellows
130	Ocarina	Ocarina	Bellows
131	Big Lead	Big Lead	Bellows
132	Euro-Dance	Euro Dnc	Bellows
133	LA Brass Ld	LA BrsLd	Bellows
134	CC Solo	CC Solo	Bellows
135	D-50 Fantasy	D50Fanta	Bellows
136	Fantasia	Fantasia	Bellows
137	D-Mention	DMention	Bellows
138	Silky Pad	SilkyPad	Bellows
139	Shwimmer	Shwimmer	Bellows
140	Square Pad	Sqr Pad	Bellows
141	Big Panner	BigPaner	Bellows
142	Sweep Pad	SweepPad	Bellows
143	StringsStage	StrStage	Bellows
144	Tr-Keman	TR-Keman	Bellows
145	El-Violin	ElViolin	Bellows
146	Sitar	Sitar	Keyboard
147	Oud	Oud	Keyboard
148	Bazouki Trmv	BzkTrm	Keyboard
149	Oud2Trm VMix	Oud2Trm	Keyboard
150	Truba	Truba	Bellows
151	IDN Bansi Lv	IDNBansi	Bellows
152	Nay Live	Nay Live	Bellows
153	Kawala	Kawala	Bellows
154	Frula	Frula	Bellows
155	Shakuhachi	Shaku	Bellows
156	Mizmar Oct	MizmrOct	Bellows
157	HighLand	HighLand	Bellows
158	Zampogna	Zampogna	Bellows
159	Tamboura	Tamboura	Bellows
160	Weather Ld	WeathrLd	Bellows
161	Timpani	Timpani	Keyboard
162	Steel Drums	SteelDrm	Keyboard

No.	Full Name	FR-4x Name	What can be controlled
The following sounds require that the "Balkan" expansion sound data be loaded as described in "Loading Expansion Sounds" of the reference manual. If this data is not loaded, these sounds cannot be selected.			
MEMO			
<ul style="list-style-type: none"> The "Balkan" expansion sound data is already preloaded when the instrument is shipped from the factory. The sounds that can be selected differ depending on the type of expansion sounds that are loaded. 			
163	Tamburica Contra /Stop	TambCont	Keyboard
164	Tamburica Prim Trill	TambPrim	Bellows
165	Tamburica Prim Trill (Keyboard)	TambPrmK	Keyboard
166	Tamburica Bass /Stop	TambBass	Keyboard
167	E. Guitar /2	E. Guitar	Keyboard
168	E. Guitar Tremolo	E. GtTrm	Bellows
169	E. Guitar Tremolo (Keyboard)	E. GtTrmK	Keyboard
170	Pick Bs Line	Pick Bs	Keyboard
171	Balkan Violin	BLK Vln	Bellows
172	Balkan Clarinet /2	BLK Cla1	Bellows
173	Trumpet Soft wPad	TpSft wP	Bellows
174	Sax /2 wPad	Sax wPad	Bellows
175	Or. Sax/2 wPad	OrSax wP	Bellows
176	Bouzuki	Bouzuki	Keyboard
177	EEU-Gajde	EEUGajde	Bellows
178	Balkan Clarinet	BLK Cla2	Bellows
179	Balkan Sax	BLK Sax	Bellows

Controlling the Dynamics of the Orchestra Sound

The FR-4x lets you vary the dynamics of the sound by the strength (velocity) with which you play the keyboard and the force with which you operate the bellows.

Whether the sound is controlled by the keyboard or by the bellows, or by both, depends on the sound, and is listed in the preceding **"Orchestra Tone List."**

The following table describes the method of controlling the dynamics for each sound.

What can be controlled	Method of controlling the dynamics
Bellows	If one of these sounds is selected, the bellows controls the dynamics (expression) of the sound.

Keyboard	<p>The dynamics of the sound varies according to how strongly (how fast) you play a key.</p> <p>You can edit the “Touch (Orchestra Touch)” parameter (see the reference manual) to specify the velocity sensitivity when playing orchestra sounds.</p> <p>NOTE</p> <p>“Touch (Orchestra Touch)” can be edited only if you’ve selected a sound that is controlled only by the keyboard. (If this cannot be edited, it is displayed as “----.”)</p>
Bellows + Keyboard	<p>The dynamics of the sound vary according to your keyboard playing strength and according to the force with which you operate the bellows.</p>

Organ Tone List

No.	Full Name	What can be controlled
P1	TYPLJAZZ	Bellows
P2	JAZZORGN	Bellows
P3	JZBALLAD	Bellows
P4	OCTPLAY	Bellows
P5	FULLDRAW	Bellows
P6	POPULAR	Bellows
P7	LIGHTJAZ	Bellows
P8	BOSSA	Bellows
P9	LATIN	Bellows
P10	LATINVAR	Bellows
P11	ROCK	Bellows
P12	OLDFSHN2	Bellows
P13	CHURCH	Bellows
P14	BLUES	Bellows
P15	DISTORT	Bellows
P16	PROGRESV	Bellows
P17	THEATRE	Bellows
P18	AMERICA	Bellows
P19	HOUSPERC	Bellows
P20	3rdPERC	Bellows
P21	OVD2ndPR	Bellows
P22	GOSPEL	Bellows
P23	CLARINET	Bellows
P24	OBOE	Bellows
P25	TRUMPET	Bellows
P26	FULTE	Bellows
P27	TIBIA	Bellows
P28	VOX	Bellows
P29	FULORGAN	Bellows
P30	ENGLHORN	Bellows
P31	SAXOPHNE	Bellows
P32	FROHORN	Bellows

Drum Tone List

Number	Name	CC00	CC32	PC
1	Pop+Perc	0	0	1
2	Pop+Vo	0	0	2
3	OldFR-7x	0	0	3

	Pop+Perc	Pop+Vo	OldFR-7x	
0	C-1	SeaShells	HipHop Kick1	Pop BD1
1	C#-1	Equat-nutshells	Jazz Kick 1	Pop BD2
2	D-1	Cascade_Ending	Mex Kick	Folk BD
3	D#-11	Chimes-Ending	Rm Kick 1	Jazz BD1
4	E-1	Chimes&Seeds_1	Rm Kick 2	Jazz BD2
5	F-1	CrashPhrase4	HipHop Kick2	Jazz BD3
6	F#-1	CrashPhrase5	TechnoKick1	Jazz BD4
7	G-1	RidePhrase1	BassDrumSet	Mex BD
8	G#-1	RidePhrase2	HipHop Kick1	TR-909 BD
9	A-1	Chimes	909Comp Kick	HipHop BD1
10	Bb-1	St Kick 1	St Kick 1	HipHop BD2
11	B-1	JazzKick	JazzKick	Techno BD1
12	C0	NewRockKik 1	NewRockKik 2	Techno BD2
13	C#0	Cymbal Roll	Cymbal Roll	Jungle BD
14	D0	Rock Stick 1	Rock Stick 2	Concert BD
15	D#0	Rm Snare 1	Rm Snare 1	Folk SD
16	E0	Rm Snare 2	Rm Snare 2	Pop SD1
17	F0	St Snare3	St Snare1	Pop SD2
18	F#0	St Snare2	St Snare2	Jazz SD
19	G0	NewJzSn2	NewJzSn2	Concert SD
20	G#0	NewJzSn1	NewJzSn1	TR-909 SD1
21	A0	R&B Snare	R&B Snare	TR-909 SD2
22	Bb0	RockSnare2_2	RockSnare2_2	Dance SD
23	B0	RockSnare1_2	RockSnare1_2	Power SD
24	C1	PopSnare38 1	PopSnare38 1	Ghost SD1
25	C#1	Snare Ghost1	Snare Ghost1	Ghost SD2
26	D1	PopSnare38 2	PopSnare38 2	Brush SD
27	D#1	FingerSnaps2	FingerSnaps2	Snare Roll
28	E1	909 HandClap	909 HandClap	Pop Stick1
29	F1	808 Clap	808 Clap	Pop Stick2
30	F#1	Hand clap2	Hand clap2	Pop Hi Hat1
31	G1	909 HandClap	909 HandClap	Pop Hi Hat2
32	G#1	Pedal Hi Hat	Pedal Hi Hat	Pop Hi Hat3
33	A1	GospelHClp1	GospelHClp1	Jazz Hi Hat
34	Bb1	Snare Roll 1	Snare Roll 1	808 Hi Hat
35	B1	Pop Kick 35	Pop Kick 35	909 OH
36	C2	Pop Kick 36	Pop Kick 36	TR-707 HH1
37	C#2	Pop Stick1	Pop Stick1	TR-707 HH2
38	D2	PopSnare38 3	PopSnare38 3	CR-78 HH1
39	D#2	Snare Ghost1	Snare Ghost1	CR-78 HH2
40	E2	PopSnare40 1	PopSnare40 1	Pop Ride1
41	F2	Flam Tom 41	Flam Tom 41	Pop Ride2
42	F#2	Pop Hi Hat1	Pop Hi Hat1	Jazz Cym1
43	G2	Tom 43	Tom 43	Ride Bell
44	G#2	Pop Hi Hat2	Pop Hi Hat2	Dance Cym
45	A2	Flam Tom 45	Flam Tom 45	606 Cym
46	Bb2	Pop Hi Hat3	Pop Hi Hat3	Concrt Cy1
47	B2	Tom 47	Tom 47	Concrt Cy2
48	C3	Flam Tom 50	Flam Tom 50	Big Gong

Drum Tone List

		Pop+Perc	Pop+Vo	OldFR-7x
49	C#3	Pop Cymbal2	Pop Cymbal2	Small Gong
50	D3	Tom 50	Tom 50	Bend Gong
51	D#3	Pop Ride1	Pop Ride1	RAMA Cym
52	E3	Pop Cymbal	Pop Cymbal	Tambourin1
53	F3	Pop Ride2	Pop Ride2	Tambourn2
54	F#3	Tambourine	Tambourine	Shake Tamb
55	G3	Splash Cym.	Splash Cym.	Jingle Bell
56	G#3	ChaChaCowb	ChaChaCowb	Cowbell
57	A3	CrashCymbal2	CrashCymbal2	Claves
58	Bb3	Vibraslap	Vibraslap	Castanets
59	B3	RockRideCym1	RockRideCym1	Woodblock1
60	C4	NewHiBongo	NewHiBongo	Woodblock2
61	C#4	NewLoBongo	NewLoBongo	Shaker
62	D4	NewCongaSlp	NewCongaSlp	Shekere
63	D#4	NewCongaOp	NewCongaOp	Triangle 1
64	E4	NewLoConga	NewLoConga	Triangle 2
65	F4	Timbal Hi	Timbal Hi	Hand Clap
66	F#4	Timbal Lo	Timbal Lo	Finger Snap
67	G4	Agogo 1	Agogo 1	ShrWhistle
68	G#4	Agogo 2	Agogo 2	LongWhistle
69	A4	NewShaker2	NewShaker2	Quide
70	Bb4	NewShaker1	NewShaker1	Guiro
71	B4	ShrtWhistle	ShrtWhistle	Caxixi
72	C5	LongWhistle	LongWhistle	Hoo Lo
73	C#5	Quide1	NewQuide1	Hoo Mid
74	D5	Quide2	NewQuide2	Tom Lo
75	D#5	Claves	NewClaves	Tom Mid
76	E5	Woodblock1	Woodblock1	HiBongo
77	F5	Woodblock2	Woodblock2	LoBongo
78	F#5	Mute Cuica	Mute Cuica	CongaSlap
79	G5	Open Cuica	Open Cuica	CongaOp
80	G#5	MuteTriangl	MuteTriangl	909 TomL
81	A5	OpenTriangl	OpenTriangl	909 TomM
82	Bb5	Shaker	Shaker	909 TomH
83	B5	Jingle Bell	Jingle Bell	Synth Dr 1
84	C6	Bell Tree	Bell Tree	Synth Dr 2
85	C#6	Castanets	Castanets	Tamorra 1
86	D6	Mute Surdo	Mute Surdo	Tamorra 2
87	D#6	Open Surdo	Open Surdo	Tamorra 3
88	E6	Cana	Cana	Pandeiro 3
89	F6	Timbal HiFlm	Timbal HiFlm	Pandeiro 4
90	F#6	Timbal LoFlm	Timbal LoFlm	Pandeiro 5
91	G6	NewTmbI PH S	NewTmbI PH S	Timpni E
92	G#6	NewShekere1	NewShekere1	Timpni F
93	A6	NewShekere2	NewShekere2	Timpni F#
94	Bb6	NHBngoMute	NHBngoMute	Timpni G
95	B6	L BongoMute	L BongoMute	Timpni Ab
96	C7	CajonHi	CajonHi	Timpni A
97	C#7	CajonHiFlm	CajonHiFlm	Timpni Bb
98	D7	Cajon Low	Cajon Low	Timpni B
99	D#7	CajonLoFlm	CajonLoFlm	Timpni C
100	E7	FlmncoHClap1	FlmncoHClap1	Timpni C#
101	F7	FlmncoHClap2	FlmncoHClap2	Timpni D
102	F#7	BongoCowBell	BongoCowBell	Timpni Eb
103	G7	PopSnareFl	AfHey	Timpni E1
104	G#7	MamboCowBell	MamboCowBell	Wadaiko

		Pop+Perc	Pop+Vo	OldFR-7x
105	A7	PopSnareDrag	MexFVox2	Wadko Rim
106	Bb7	Pop Stick1	AfFoods	Shimedaik
107	B7	PopSnare38 3	MexFVox1	Atarigane
108	C8	Snare Ghost1	MexMVox1	Hyoushigi
109	C#8	PopSnare40 1	YodelFVox1	Ohkawa
110	D8	Flam Tom 41	MexMVox2	Kotsuzumi
111	D#8	Pop Hi Hat1	YodelMVox1	Udo Long
112	E8	Tom 43	MexMVox3	Req Dum
113	F8	Pop Hi Hat2	FlmncoFVox1	Tabla Te
114	F#8	Flam Tom 45	YodelFVox2	Tabla Na
115	G8	Pop Hi Hat3	FlmncoFVox2	Talking Dr
116	G#8	Tom 47	NewWhistle1	DjembeRim
117	A8	Flam Tom 50	FlmncoFVox3	Timbl Paila
118	Bb8	Pop Cymbal2	NewWhistle2	CongaSlide
119	B8	Tom 50	FlmncoMVox1	Mut Pandr
120	C9	Pop Ride1	FlmncoMVox2	Rain
121	C#9	Pop Cymbal	BrazilVox1	Thunder
122	D9	Pop Ride2	FlmncoMVox3	Wind
123	D#9	Splash Cym.	BrazilVox2	Seashore
124	E9	CrashCymbal2	BrazilVox3	Bird1
125	F9	BrushSnare Shot	AfAahhh	Bird2
126	F#9	Jazz Hat2	---	Gun Shot
127	G9	Jazz Hat3	---	---

User Program List

This is the user program list when the instrument is shipped from the factory (following factory reset). It can be rewritten.

Bank	Number	UPG Name
1	1	Classic 1
	2	Classic Acc and Orch
	3	Concerto
	4	A LA BACH Classical
	5	Barocco Acc
	6	Astor Ave Maria
	7	Ave Maria
	8	Concerto Bells
	9	Epic Travels
	10	Persian Orchestral
	11	Lamento Classic
	12	New Solo Violin Orc
	13	Soft Church OrganAcc
	14	Oboe Solo
2	1	Welcome To Broadway
	2	Swing Jazz Organi
	3	Swing Jazz Uni
	4	Swing Jazz Uni full
	5	Art Jazz
	6	Acoustic Piano
	7	Charlie Sax
	8	Organ & Ham
	9	Take THe Vocals
	10	The AccSax Section
	11	SaxoJazz Quartet
	12	Scat Accordion Trans
	13	Buddy Clarinet Swin
	14	Kenny and Toots
3	1	BalMuset 1
	2	BalMuset 2
	3	Muset Bolero Drums
	4	Muset Bolero
	5	Paso Muset
	6	ChaChaCha Muset
	7	La Foule Latin
	8	Romance Flute Muset
	9	Italian BallRoom
	10	Valse Muset 1
	11	Valse Muset 2
	12	Vasle Muset 3
	13	Vasle Muset 4
	14	Vienna muset

Bank	Number	UPG Name
4	1	Kvartett 01
	2	Kvartett acoustic
	3	STORGAARDS BALL
	4	kvartett m clarinett
	5	OLA'S SPELEMANNSLAG
	6	ACCORDION-BRASS
	7	TW (SW REG
	8	MUSETTE +
	9	MUSETTE SAX HIGH
	10	GETZ A PARIS
	11	ELPIANO - GIG
	12	SILKYPAD
	13	Roland Fantasy
	14	PIANOMAN
5	1	Medium Jazz
	2	Smooth Jazz
	3	Dixieland Jazz
	4	Wet Musette
	5	Paris Streets
	6	Mellow Musette
	7	Basic Techno
	8	Brass Techno
	9	Symphonic Techno
	10	Euro Techno
	11	Classic Polka
	12	Alpine Polka
	13	Mellow Polka
	14	Latin Flair
6	1	Jz Club
	2	Art Jazz
	3	Italia
	4	Bossa
	5	Django
	6	Samba
	7	1950
	8	Conjnto
	9	Zydeco
	10	HappySng
	11	PTango
	12	Funky
	13	Benny
	14	Rock It

Bank	Number	UPG Name
7 (*1)	1	REE Violins
	2	REE Tambura Pad
	3	REE Tamburasi
	4	REE Tamburasi Acc
	5	REE Trubaci Pad
	6	REE Trubaci
	7	REE Trubaci Clar
	8	REE Frula
	9	REE Kawala
	10	REE Tremolo
	11	REE BasGtr Accordion
	12	REE BasGtr Sax
	13	REE BasGtr ElViolin
	14	REE BasGtr Sax Acc

*1 The **"Balkan"** expansion sound data must be loaded as described in **"Loading Expansion Sounds"** of the reference manual.

NOTE

- The **"Balkan"** expansion sound data is already preloaded when the instrument is shipped from the factory.
- If this data is not loaded, there will be no sound.